

CG-5 STREET GUITAR AMPLIFIER



IMPORTANT SAFETY INSTRUCTIONS

Please read before using this product and strictly follow the owner's manual
Please keep this manual for future reference.

1. Connect the amplifier ONLY to a properly grounded AC outlet of the proper voltage for your amp.
2. Avoid the thread to be under kick or heavily hustled.
3. Do not block any ventilation openings on this amplifier.
4. Do not operate near any heat source.
5. Do not expose this amplifier to rain or moisture.
6. Disconnect the power cord if the amplifier is not in use for longer period.
7. To reduce the risk of electric shock, DO NOT remove the cover.

CAUTION

Voltage: AC 220V~50Hz



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



To reduce the risk of fire or electric shock. Do not expose this apparatus to rain or moisture. To reduce the risk of electric shock. Do not remove cover. Refer servicing to qualified service personnel for repair this apparatus.


The exclamation point within an equilateral triangle is intended to alert you to the presence of important operating and servicing instructions.

The lighting flash & arrowhead symbol, within an equilateral triangle, is intended to alert you to the presence of danger.

SPECIAL INSTRUCTIONS FOR BATTERY AMPLIFIER

1. When connecting AC Power Supply, the chargeable circuit works under power on/off mode.
Please disconnect AC Power Supply if the unit is not in use or the battery full charged.
2. Under CHARGE mode, the charge indicator is bright; the indicator is extinct when battery full charged.
3. To prolong the battery life and saving your cost, suggest using AA type Ni-MH rechargeable (x10) battery, Maximum 10-hour continuous use.
4. When using dry battery, please DISCONNECT AC Power Supply.

PANEL DESCRIPTION



1.INPUT (1/4" MONO)

Use this jack to connect your guitar to the amplifier.

2.HEADPHONE (1/4" MONO)

Use this jack to connect headphone for silent practice. The internal speaker is disconnected when this jack is used.

3.GAIN

Use this control to switch the mode of Clean, Driver and Distortion. Adjust the gain level of each mode according to the indication on the panel of this control.

4.BASS

Use this control to cut or boost the LOW level of this amplifier.

5.TREBLE

Use this control to cut or boost the HIGH level of this amplifier

6.LEVEL

Use this control to adjust the output level of the amplifier.

7.POWER


Use this switch to turn the amplifier on/off.

8.CHARGE INDICATOR

9.WORK INDICATOR

SPECIFICATION

| | |
|------------------------------------|-----------------------------------|
| Output (RMS) ----- | 5W |
| Input Sensitivity/ Impedance ----- | INPUT -10dBu/1M Ω |
| Speaker/ Impedance ----- | 6.5 inch/4 ohm |
| Controls ----- | Gain, Bass, Treble, Level |
| Connections ----- | Input (1/4") |
| ----- | Headphone (1/4") |
| Indicator ----- | POWER LED |
| ----- | CHARGE INDICATOR |
| Power Supply ----- | AC 220V~50Hz |
| Dimension ----- | 235x155x235 mm |
| Packing Size ----- | 270x190x280 mm |
| Net Weight ----- | 3.1kg (not including battery) |
| Gross Weight ----- | 3.4kg (not including battery) |
| Options ----- | AA type rechargeable battery x 10 |
| ----- | Strap |



GUITAR AMPLIFIER

Beta Aivin continually develops new products, as well as improves existing ones. For this reason, the specifications and information in this manual are subject to change without notice.